


Fully automatic snap attaching machine



FT-300 PARTS DESCRIPTION



NOTE: Typically two machines are required to complete a full set of press fastener. One machine is for attaching Part 1 (*Cap & Stud*) and another machine is for Part 2 (*Socket & Post*). Only one fixed size of snap can be attached. Using other types or sizes of snap will cause machine malfunctioning and machine will not work properly.

